

WOOD SPLITTER

PAT IN BUILDING

FIRE WOOD

FIRE WOOD

SIDING

PAT IN BUILDING

METAL
FRAMES

WINDOWS
PAT IN
BUILDING

DRAIN
TUBE

WIRE
MESH

(FLOOR)

(FLOOR)

PAT IN BUILDING

REMOVE:
PICKING UP

(11-2-13)

REMOVE
(BY 10-28-13)

1" X 8" X 12"

PLYWOOD

REMOVE
(10-28-13)

SCAFFOLDING

(10-28-13)

TRAILER

Block

PATIO

8" FACE
Block

PATIO

REMOVE

4" FACE
Block

GABLE
END

4" FACE
Block

GABLE
END

8" Block

(PATIO)

Doors
for
building

REMOVE

MIXER

Need
this for
LAST
BLOCK
WORK ON
GABLE
ENDS

House

Paving
Brick
(PATIO)

