

WOOD SPLITTER

PUT IN BUILDING

FIRE WOOD

FIRE WOOD

SIDING
PUT IN BUILDING



METAL
FRAMES

WINDOWS
PUT IN
BUILDING

WIRE
MESH
(FLOOR)
PUT IN BUILDING
(11-2-13)

REMOVE:
PICKING UP
(11-2-13)

DRAIN
TUBE

REMOVE
(BY 10-28-13)

1" 8" X 12'

PLYWOOD

REMOVE
(10-28-13)

SCAFFOLDING

(10-28-13)

TRAILER

Block

PATIO

4" FACE
BLOCK
GABLE
END

4" FACE
BLOCK
GABLE
END

(PATIO)

8" FACE
BLOCK
PATIO

REMOVE

Doors
for
building

REMOVE

MIXER

Need
this for
LAST
BLOCK
WORK ON
GABLE
ENDS

Paving
Brick
(PATIO)



House