

1177-1179 St. Paul Ave, St. Paul, MN

General Construction

Demolition:

- 1. All work shall include "normal" demolition work required
- 2. Drywall removal/patch/repair to repair current missing pieces and damaged areas.
- Complete the demolition checklist
- 4. Save door stops/hinges wherever possible
- Save Smokes / CO2's if possible
- 6. Save Kitchen Cabinets DO NOT DEMO
- Save kitchen and dining room light fixtures
- 8. Remove both bathroom vanities
- 9. If plumbing valves do not leak do not replace

Exterior and Landscaping:

- Landscape per landscape plan (attached)
- 2. Ensure proper drainage away from foundation
- 3. Remove center tree, fill in and seed for lawn.
- 4. Remove Bushes on inner corner (closes to sidewalk)
- Install new plants/rock/plastic etc according to plan (attached)
- 6. Trim all saved trees to healthy height
- 7. Clean up center garden area, rock and install crescent edger's
- 8. Install crescent edger's to 1177 side.
- 9. Install landscaping plastic on all front garden area's
- 10. Install landscape rock in all front garden area's
- 11. Replace all windows Both Units
- 12. New gutter on rear of house
- 13. Replace service door at 1177 32" LH
- 14. Repair Gutters on front corner of house (both 1177 & 1179 outside corners)
- 15. All new siding, LP and Stone on Front, Vinyl Triple 3 on back 3 sides, with 8" rub rail as bottom course next to driveway. See attached siding plan.
- 16. Repair rear fence between yards
- 17. Repair fence gates
- 18. Stain All exterior privacy Fencing

1177 Rear Side:

- 19. Demo Garage, pad, walk to rear stoop.
- 20. Remove Tree's behind garage and the three on the inside of the fence near garage door.
- 21. Paint Garage at 1177 To Match Triple 3 Blue Color

1179 Rear Side:

- 22. Clean up rear garden bed nearest to shed
- 23. Remove timbers on inside of fence area all of them.



- 24. Remove timbers on shared fence area move Hasta plants over to garden bed near garage.
- 25. Straighten out garden bed closest to Garage install edging, rock around Hasta plants.
- 26. Leave concrete pad
- 27. Clean up garden area outside the fence nearest garage/driveway, leave timbers, rock and add hastas.

1179 Interior Work:

- 1. Demo Carpet/Flooring
- 2. SAVE Bathtub and Bathroom Flooring
- Demo all bathroom wall tile, save floor tile and toilet, remove sink, save mirror cabinet, remove toilet topper.
- 4. Closets remove shelving and store safely. Leave brackets in place that make sense to re-install normal amounts of closet shelving
- 5. Closets Re-Install Shelving once painting is complete
- 6. Remove all interior window trim and save
- 7. Remove all interior base trim and save
- 8. Patch all holes, nails, patches, etc. needed and match texture
- 9. Install new 48" bi-fold door or repair current furnace doors
- 10. Repair replace door stops as necessary Install door stops prior to locksets
- 11. Install all new door hardware, interior and exterior, including cabinetry
- 12. Check for 3 smokes (each BR) and 1 smoke CO combo for hall.
- 13. Scrape and repaint rear door
- 14. Install new 36" Front Door
- 15. Fix all floor squeaks, prior to flooring going in.
- 16. Thoroughly Clean Crawl Space, install 3 utility lights on switch
- 17. Foam all penetrations in crawl space and ensure rim joist is well insulated
- 18. Lay down HEAVY MIL plastic in crawl space, with minimum 2' overlap on seams
- 19. Install new smoke & CO2 per code white
- 20. Install all new light fixtures throughout
- 21. Re-install washer/dryer
- 22. Install all new appliances
- 23. Install granite countertops (color TBD)
- 24. Tile shower Surround
- 25. Install base and casing trim after wood floor (4.25 and 2.25 colonial)
- 26. Install bathroom wall fixtures (TP and Towel Into STUDS)

1177 Interior Work:

- Demo Carpet/Flooring
- 2. SAVE Bathtub and Bathroom Flooring
- 3. SAVE All BR Carpet
- 4. SAVE Dark Brown Paint in front Bedroom
- 5. SAVE 2 bedroom lights
- 6. Demo all bathroom wall tile, save floor tile and toilet, remove sink, save mirror cabinet, remove toilet topper.

1177-1179 St. Paul Ave Page 2 of 5



- 7. Closets remove shelving and store safely. Leave brackets in place that make sense to re-install normal amounts of closet shelving
- 8. Closets Re-Install Shelving once painting is complete
- 9. Remove all interior window trim and save
- 10. Remove all interior base trim and save
- 11. Patch all holes, nails, patches, etc. needed and match texture
- 12. Install new 48" bi-fold door or repair current furnace doors
- 13. Repair replace door stops as necessary Install door stops prior to locksets
- 14. Install all new door hardware, interior and exterior, including cabinetry
- 15. Check for 3 smokes (each BR) and 1 smoke CO combo for hall.
- 16. Scrape and repaint rear door
- 17. Install new 36" Front Door
- 18. Install new 32" RH Rear Door
- 19. Fix all floor squeaks, prior to flooring going in.
- 20. Thoroughly Clean Crawl Space, install 2-3 lights on switch
- 21. Foam all penetrations in crawl space and ensure rim joist is well insulated
- 22. Lay down HEAVY MIL plastic in crawl space, with minimum 2' overlap on seams
- 23. Install new smoke & CO2 per code white
- 24. Install all new light fixtures throughout
- 25. Re-install washer/dryer
- 26. Install all new appliances
- 27. Tile shower Surround
- 28. Install base and casing trim after wood floor (4.25 and 2.25 colonial)
- 29. Install bathroom wall fixtures (TP and Towel Into STUDS)
- 30. Install new granite C-TOPs

1179 Garage:

- 1. Tear Down and re-build Garage 21'x16'
- 2. Basic Design to match 1177 garage but with 6" curb or 8" block on top of slab, door inside fence facing east, 1 window facing north, 3 roof vents facing south.
- 3. Triple 3 siding to match house, LP wide trim on OHD and Side Door and Window

1177-1179 St. Paul Ave Page 3 of 5



Electrical

- 1. Replace GFI's if not white
- 2. Connect Dishwasher
- 3. Wire new garage, GDO, single light on switch, exterior lights on switch (2 front, 1 side)
- 4. Install 6 can lights in living room on dimmer switch
- 5. MC-Replace all new light fixtures (save 2-3 fixtures for re-use in 1177)
- 6. MC-Index Fuse Box
- 7. MC-Thoroughly clean switches and receptacles
- 8. MC-Install new cover plates throughout

Plumbing

- 1. Install 2 kitchen sink (no disposal) (single bowl)
- 2. Install 2 Dishwasher
- 3. Install 2 Fridge Water
- 4. Install 2 Bathroom Faucets
- 5. Install 2 Bathroom Toilets
- 6. Install 2 Bathroom Shower Valves
- 7. 1177 New Exterior Spigot (check other side too)
- 8. Replace valves as necessary (1/4 turn)

Mechanical HVAC

- Clean ductwork upon completion (\$150 budget max)
 - a. Or just have our guys vacuum everything out really good
- 2. Install new Filter boxes
- Replace both furnace filters
- 4. Thoroughly clean out furnaces and test
- Install bath fans in both bathrooms, on with switch
- 6. Option price to install AC (use existing A-Coil)

Flooring

- 1. Save Bathroom Tile floor in both units, repair as necessary
- 2. Install new vinyl flooring in kitchen and dining areas (with new underlayment)
- 3. Install new Tile at entry
- 4. Install wood floor in living room and hall
- 5. Install new carpet in all bedrooms (fix any floor squeaks and scrape clean floor prior to carpet)
- 6. Repair subfloor as needed for appropriate floor installations (tile / wood / carpet / etc.)



Painting

- 1. Paint all Ceiling and Closets CHB (flat)
- 2. Paint all living spaces Accessible Beige (flat)
- 3. Paint all bedrooms Tony Taupe (flat) (Master Bedroom at 1179 can stay brown)
- 4. Paint Kitchen (3 walls) and bathroom Sand Fossil (satin)
- 5. Paint all trim Pro Classic Extra White Satin
- 6. Painting contractor to fill small holes from nails/tacks/screws/etc. Large repairs completed by general contractor.